


Using Enclosed Cabs for Reducing DPM Exposures


James Noll
NIOSH



Equipment can have pressurized cab



Cabs can be very efficient in reducing DPM exposures



Two Key Components

- **Effective Filtration**
- **Cab Integrity**





Effective Filtration

- 1. Pressurized Intake**
- 2. Recirculated Cab Air**




Pressurized Intake (Outside) Air

- **40 – 140 cfm**
- **At least 25 cfm per worker to dilute CO₂**
- **MERV-16 mechanical filter**
- **Powered Unit : Self-cleaning or centrifugal design**



Recirculated Cab Air




Recirculated Cab Air

- Effectiveness is by multiple passes through filter media
- Substantial reduction in cleaning time from in-cab dust sources
- MERV 14 -16 rated filter media
- 3-4 times the intake airflow quantity (200-300 cfm typical)



Cab Integrity

**Installing new doors gaskets and
seals/plugging and sealing cracks and holes**



Pressure Monitoring Testing

**Outside tubing location
for pressure monitor**




Data logger and Pressure Monitoring System






Caution
Equipment
Company

IRON
LIFE



Effect of work practices





Evaluation of Enclosed Cabs




Bolter



Drill




Enclosed cab design





PRESSURE




NIOSH 5040 EC/TC





REAL TIME EC






Cab Door Opening







Limitations



- **Maintenance**
 - Change filters
 - Cab integrity



Limitations



- Maintenance
 - Change filters
 - Cab integrity
- **Not all vehicles have an effective enclosed cab**
 - Size
 - Visibility



Limitations



- Maintenance
 - Change filters
 - Cab integrity
- Not all vehicles have an effective enclosed cab
 - Size
 - Visibility
- **Not all miners can work in enclosed cabs**



Questions???

James Noll

jnoll@cdc.gov

412-386-6828

